

Parts List



(2) TANK BODIES
(2) BILLET CLAMPS
(2) 90 DEGREE ½” BARBED FITTINGS
(1) 90 DEGREE 3/8” BARBED FITTING
(1) STRAIGHT 3/8” BARBED FITTING
(1) STAINLESS STEEL BRACKET
(1) LENGTH OF 3/8” I.D. HOSE
(1) LENGTH OF 1/2” I.D. HOSE
(8) 1/4 X 20 SHCS X 5/8

For Technical Assistance, call Moroso’s Tech Line
(203)-458-0542, 8:30am-5:00pm Eastern Time
MOROSO PERFORMANCE PRODUCTS, INC.
80 CARTER DRIVE
GUILFORD, CT 06437
www.moroso.com





Step 1: Remove vacuum line shown and label as line #1.



Step 2: Remove vacuum line shown and label as line #2.

For Technical Assistance, call Moroso's Tech Line
(203)-458-0542, 8:30am-5:00pm Eastern Time
MOROSO PERFORMANCE PRODUCTS, INC.
80 CARTER DRIVE
GUILFORD, CT 06437
www.moroso.com





Step 3: Locate and remove shifter cable mounting bracket bolts.


For Technical Assistance, call Moroso's Tech Line
(203)-458-0542, 8:30am-5:00pm Eastern Time
MOROSO PERFORMANCE PRODUCTS, INC.
80 CARTER DRIVE
GUILFORD, CT 06437
www.moroso.com






Step 4: Install stainless mounting bracket as shown.

For Technical Assistance, call Moroso's Tech Line
(203)-458-0542, 8:30am-5:00pm Eastern Time
MOROSO PERFORMANCE PRODUCTS, INC.
80 CARTER DRIVE
GUILFORD, CT 06437
www.moroso.com





Step 5: Re-install stock bolts previously removed.



Step 6: Install Billet clamp saddles as shown with relief groove facing down, use (4) ¼-20 SHCS and tighten.


For Technical Assistance, call Moroso's Tech Line
(203)-458-0542, 8:30am-5:00pm Eastern Time
MOROSO PERFORMANCE PRODUCTS, INC.
80 CARTER DRIVE
GUILFORD, CT 06437
www.moroso.com





Step 7: Install billet clamps using (4) ¼-20 SHCS. Do not tighten.

For Technical Assistance, call Moroso's Tech Line
(203)-458-0542, 8:30am-5:00pm Eastern Time
MOROSO PERFORMANCE PRODUCTS, INC.
80 CARTER DRIVE
GUILFORD, CT 06437
www.moroso.com




Step 8: Assemble Air Oil Separators as shown using Teflon Tape on all fittings.



Step 9: Install Air Oil separator with ½” 90 degree fittings (towards front of vehicle) in front billet clamp.

For Technical Assistance, call Moroso’s Tech Line
(203)-458-0542, 8:30am-5:00pm Eastern Time
MOROSO PERFORMANCE PRODUCTS, INC.
80 CARTER DRIVE
GUILFORD, CT 06437
www.moroso.com




Step 10: Set height between 1” and 1 1/8”, tighten clamp. This will allow bottom cup to be unscrewed for draining.



Step 11: Install Air Oil separator with 3/8” fittings in rear billet clamp.

For Technical Assistance, call Moroso’s Tech Line
(203)-458-0542, 8:30am-5:00pm Eastern Time
MOROSO PERFORMANCE PRODUCTS, INC.
80 CARTER DRIVE
GUILFORD, CT 06437
www.moroso.com



Step 12: Set height between 1” and 1 1/8”, tighten clamp. This will allow bottom cup to be unscrewed for draining.



Step 13: Install 3/8” line as shown, mark and cut to desired length.

For Technical Assistance, call Moroso’s Tech Line
(203)-458-0542, 8:30am-5:00pm Eastern Time
MOROSO PERFORMANCE PRODUCTS, INC.
80 CARTER DRIVE
GUILFORD, CT 06437
www.moroso.com






Step 14: Install cut end to 3/8” straight barbed fitting.

For Technical Assistance, call Moroso’s Tech Line
(203)-458-0542, 8:30am-5:00pm Eastern Time
MOROSO PERFORMANCE PRODUCTS, INC.
80 CARTER DRIVE
GUILFORD, CT 06437
www.moroso.com




Step 15: Remove outer shell from line previously marked line #1.



Step 16: Route line #1 as shown to 3/8” 90 degree fittings.

For Technical Assistance, call Moroso’s Tech Line
(203)-458-0542, 8:30am-5:00pm Eastern Time
MOROSO PERFORMANCE PRODUCTS, INC.
80 CARTER DRIVE
GUILFORD, CT 06437
www.moroso.com




Step 17: Install ½” hose to valve cover nipple and route to front Air Oil Separator as shown.



Step 18: Remove outer shell from line previously marked line #2.


For Technical Assistance, call Moroso’s Tech Line
(203)-458-0542, 8:30am-5:00pm Eastern Time
MOROSO PERFORMANCE PRODUCTS, INC.
80 CARTER DRIVE
GUILFORD, CT 06437
www.moroso.com



Step 19: Route line #2 to fitting as shown, mark and cut to correct length.



For Technical Assistance, call Moroso's Tech Line
(203)-458-0542, 8:30am-5:00pm Eastern Time
MOROSO PERFORMANCE PRODUCTS, INC.
80 CARTER DRIVE
GUILFORD, CT 06437
www.moroso.com




Step 20: Install line #2.



Installation complete

For Technical Assistance, call Moroso's Tech Line
(203)-458-0542, 8:30am-5:00pm Eastern Time
MOROSO PERFORMANCE PRODUCTS, INC.
80 CARTER DRIVE
GUILFORD, CT 06437
www.moroso.com



To empty Air Oil Separator, unscrew bottom, dump collected oil and re-install.
Be sure that o-ring is in place before re-installing bottom.

Draining of Air Oil Separator is needed; this will depend on driving conditions (i.e.) normal day to day driving check every 1,000 miles until a baseline is established. A good baseline is to drain the Air Oil Separator when it is about HALF full. This will vary with temperatures (cold winters vs. hot summers). For track usage Air Oil Separator will need to be drained after every outing.

For Technical Assistance, call Moroso's Tech Line
(203)-458-0542, 8:30am-5:00pm Eastern Time
MOROSO PERFORMANCE PRODUCTS, INC.
80 CARTER DRIVE
GUILFORD, CT 06437
www.moroso.com