

## CTA Radiator Pressure Tester Adapter Application Chart

Make	Model	Year	System Adapter (CTA #)	Cap Adapter (CTA#)
Acura	CL	1997	7091	7113
Acura	Integra	1990 - 1993	7092	7112
Acura	Integra	1994 - 1999	7091	7113
Acura	Legend	1991 - 1996	7091	7113
Acura	NSX	1991 -	7092	7112
Acura	RL	1996	7091	7113
Acura	TL (5 cyl)	1995 - 1998	7092	7112
Acura	TL (6 cyl)	1996 -	7091	7113
Audi	A3	2006	7098	7111
Audi	A4	1996 - 2003	7098	7111
Audi	A4	2009 - up	7098	7111
Audi	A4 Wagon	2007	7098	7111
Audi	A6	1998 - 2006	7098	7111
Audi	Q5	2009 - up	7098	7111
Audi	Q7 (3.6L)	2004	7098	7111
Audi	Q7	2009 - up	7098	7111
Audi	TT	2000 - 2002	7098	7111
Audi	w/ female threads on expansion tank	1990 - 1998	7095	7108
Audi	w/ male threads on filler neck of expansion tank	All	7093	7106
Bentley	Arnage	2000 - 2003	7096	7104
BMW	3 Series	2004 - 2005	7097	
BMW	7 Series	2002 - 2006	7097	
BMW	w/ threaded filter neck	up to 1987	7099	7104
BMW	w/ threaded filter neck (ex. 3 (E90), 5 (E60) & 6 (E63 & E64))	1988 - 2008	7097	7105
Buick	Roadmaster	1994 - 1996	7100	7109
Buick	Skylark	1992 - 1998	7100	7109
Cadillac	Catera	1997 - 2001	7100	7109
Cadillac	CTS	2003	7090	7110
Cadillac	CTS	2003	7100	7109
Cadillac	Escalade	1999	7090	7110
Cadillac	Fleetwood	1994 - 1996	7090	7110
Cadillac	Seville	1998 - 2003	7090	7110
Chevrolet	Beretta	1992 - 1996	7090	7110
Chevrolet	Camaro	1999-2002	7090	7110
Chevrolet	Caprice	1995 - 1996	7090	7110
Chevrolet	Cavalier	1995 - 1999	7090	7110
Chevrolet	Cobalt	2005	7090	7110
Chevrolet	Corsica	1992 - 1996	7090	7110
Chevrolet	Corvette	1999 - 2011	7090	7110
Chevrolet	Cruze	2011	7090	7110
Chevrolet	Express	2010 - 2011	7090	7110
Chevrolet	Impala SS	1994 - 1996	7090	7110
Chevrolet	Malibu	1997 - 1999	7090	7110
Chevrolet	Metro	1989 - 1994	7092	7112
Chevrolet	Metro	1993 - 1997	7091	7113
Chevrolet	Metro	1999	7090	7110
Chevrolet	Nova	1985 - 1988	7092	7112
Chevrolet	Prizm	1989 - 1992	7092	7112
Chevrolet	Prizm	1998	7091	7113
Chevrolet	Prizm	1999	7090	7110
Chevrolet	Silverado 1500	1999 - 2011	7090	7110
Chevrolet	Silverado 2500	1999 - 2009	7090	7110
Chevrolet	Spectrum	1985 - 1988	7092	7112

Chevrolet	Sprint	1985 - 1988	7092	7112
Chevrolet	Suburban	2000 - 2011	7090	7110
Chevrolet	Tahoe	1999 - 2011	7090	7110
Chevrolet	Tracker	1989 - 1993	7092	7112
Chevrolet	Tracker	1994 - 1998	7091	7113
Chevrolet	Tracker	1999	7090	7110
Chevrolet	Trailblazer	2001 - 2002	7090	7110
Chevrolet	Van	2007 - 2011	7090	7110
Chrysler	Colt	1984 - 1992	7092	7112
Chrysler	Colt	1993	7091	7113
Chrysler	Laser	1991 - 1998	7092	7112
Chrysler	Stealth	1991 - 1996	7092	7112
Chrysler	Summit	1993 - 1995	7091	7113
Chrysler	Talon	1991 - 1998	7092	7112
Daewoo	All	1999 - 2001	7096	7104
Dodge	Sprinter	2007 - 2013	7117	
Ford	Contour	1995 - 2001	7102	7115
Ford	Escape	2001 - 2005	7102	7115
Ford	Escape	2011	7090	7110
Ford	Escape - 2013	2012	7118	
Ford	Escort	1991 - 1999	7092	7112
Ford	E-Series Van w/threads on expansion tank	1995 - 2003	7100	7109
Ford	F-Series Truck w/threads on expansion tank	1995 - 2005	7100	7109
Ford	Excursion	2000 - 2003	7100	7109
Ford	Expedition	2003 - 2007	7100	7109
Ford	Explorer	1995 - 2001	7092	7112
Ford	Explorer	2005	7090	7110
Ford	Explorer	2002 - 2005	7100	7109
Ford	Explorer Sport Trac	2004	7092	7112
Ford	F-150	2004 - 2005	7090	7110
Ford	Festiva	1988 - 1993	7092	7112
Ford	Five Hundred	2005	7100	7109
Ford	Focus	1999	7102	7115
Ford	Focus	2000 - 2006	7096	7104
Ford	Focus	2012 - 2013	7118	
Ford	Freestyle	2005	7100	7109
Ford	Fusion	2013	7118	
Ford	Mustang	1996 - 2009	7100	7109
Ford	Ranger	2003	7092	7112
Ford	Sterling	2005	7100	7109
Ford	Taurus	1996 -	7100	7109
Ford	Taurus	2004 - 2006	7090	7110
Ford	Taurus	1996 - 2006	7100	7109
Ford	Tempo	1992 - 1994	7092	7112
Ford	Thunderbird	1989 - 1992	7092	7112
Ford	Thunderbird	2003	7100	7109
Ford	Thunderbird V6	1993 - 1997	7092	7112
Ford	Thunderbird V8	1993 - 1997	7100	7109
Ford	Topaz	1992 - 1994	7092	7112
Ford	Villager	1993 - 1999	7092	7112
Ford	Windstar	1995 - 1999	7092	7112
Ford	Windstar	2002 - 2003	7100	7109
Freightliner	Diesel Truck	2004	7090	7110
Freightliner	Diesel Truck	2004	7100	7109
GMC	Envoy	2002	7090	7110
GMC	ES250	1990 - 1991	7091	7113
GMC	Sierra 1500	1999 - 2003	7090	7110
GMC	Sierra 2500	1999 - 2003	7090	7110

GMC	Yukon	1999	7090	7110
GMC	Envoy	2002	7100	7109
Honda	Accord	1990 - 1993	7092	7112
Honda	Accord	1994 - 2009	7091	7113
Honda	Civic	1988 - 1991	7092	7112
Honda	Civic	1992 - 2005	7091	7113
Honda	Civic Hybrid	2004	7091	7113
Honda	Integra	1994 - 1999	7091	7113
Honda	Legend	1991 - 1996	7091	7113
Honda	Motorcycle	1991 - 2006	7092	7112
Honda	Odyssey	1995 - 2003	7091	7113
Honda	Pilot	2003 - 2005	7091	7113
Honda	Prelude	1990 - 1998	7092	7112
Honda	Prelude SI & VTEC	1992 - 1996	7091	7113
Hummer	H2	2003 -	7090	7110
Hyundai	All	1987 - 1999	7092	7112
Infiniti	All	1987 - 2004	7092	7112
International	466 Engine w/male threads on filler neck	1994 - 2002	7100	7109
Isuzu	All	1992 - 1997	7092	7112
Isuzu	All	1998 - 1999	7091	7113
Isuzu	Rodeo V6	2001	7092	7112
Jaguar	S Type	2000 - 2003	7090	7110
Jaguar	S Type	2000 - 2003	7100	7109
Jaguar	w/ male threads on filler neck	1990 - 1994	7096	7104
Jaguar	XJ8	1998 - 2001	7096	7104
Jaguar	XK8	1998 - 2001	7096	7104
Jaguar	X Type	2002 - 2003	7096	7104
Jeep	w/ male threads on filler neck	1987 - 1990	7094	7107
Land Rover	Discovery	2002	7097	
Land Rover	Freelander	2002	7094	7107
Land Rover	Freelander	2005	7090	7110
Land Rover	LR2	2007 - 2008	7118	
Land Rover	LR3	2005 - 2007	7090	7110
Land Rover	Range Rover	1988 - 1994	7096	7104
Land Rover	Range Rover	1995 - 2004	7097	
Land Rover	Range Rover Sport	2006	7100	7109
Lexus	ES 250	1990 - 1991	7091	7113
Lexus	ES 300	1992 - 1993	7091	7113
Lexus	ES 300	1994 - 1999	7092	7112
Lexus	GS 300	1993 - 1999	7091	7113
Lexus	GS 400	1998 - 1999	7091	7113
Lexus	LS400	1990 - 1999	7092	7112
Lexus	LX450	1996 - 1999	7092	7112
Lexus	LX470	1996 - 1999	7092	7112
Lexus	RX 300	2000	7091	7113
Lincoln	Mark VIII	1993 - 1998	7100	7109
Lincoln	Navigator	1998	7100	7109
Lincoln	Towncar	1993 - 1999	7100	7109
Mazda	3	2004 - 2006	7118	
Mazda	6	2004	7092	7112
Mazda	All (except '95 Protégé w/ 1.5L)	1985 - 1999	7092	7112
Mazda	Protégé Automatic	2000 - 2001	7092	7112
Mazda	Protégé 1.5L engine	1995 - 1995	7091	7113
Mazda	Protégé Manual	2000 - 2001	7091	7113
Mazda	Tribute	2001 - 2004	7102	7115
Mercedes	AMG	All	7101	7114
Mercedes	C class	All	7101	7114
Mercedes	CL class	All	7101	7114

Mercedes	CLK class	All	7101	7114
Mercedes	CLS class	All	7101	7114
Mercedes	E class	All	7101	7114
Mercedes	G class	All	7101	7114
Mercedes	ML 164	All	7101	7114
Mercedes	ML 320	1998 - 2005	7100	7109
Mercedes	ML 430	1998 - 2005	7100	7109
Mercedes	R class	All	7101	7114
Mercedes	S class	All	7101	7114
Mercedes	SL class	All	7101	7114
Mercedes	SLK class	All	7101	7114
Mercury	Cougar	1989 - 1992	7092	7112
Mercury	Cougar V6	1993 - 1997	7092	7112
Mercury	Cougar V8	1993 - 1997	7100	7109
Mercury	Crown Victoria	1993 - 2003	7100	7109
Mercury	Grand Marquis	1993 - 2003	7100	7109
Mercury	Mystique	1995 - 2001	7102	7115
Mercury	Sable	1996 - 2003	7100	7109
Mercury	Tracer	1991 - 1999	7092	7112
Merkur	Scorpio	1987 - 1989	7099	7104
Mini Cooper	Cooper S	All	7094	7107
Mitsubishi	3000 GT	1991 - 1998	7092	7112
Mitsubishi	Diamante	1992 - 1995	7092	7112
Mitsubishi	Diamante	1996 - 1998	7091	7113
Mitsubishi	Eclipse - Spyder	2002	7091	7113
Mitsubishi	Galant	1985 - 1993	7092	7112
Mitsubishi	Galant	1994 - 2003	7091	7113
Mitsubishi	Mirage	1985 - 1992	7092	7112
Mitsubishi	Mirage	1993 - 1999	7091	7113
Mitsubishi	Montero	1989 - 1998	7092	7112
Mitsubishi	Montero Sport	1997 - 1999	7091	7113
Mitsubishi	Outlander	2004	7092	7112
Mitsubishi	Starion	1989-1993	7092	7112
Nissan	All	1987 - 2004	7092	7112
Nissan	Altima	2006	7092	7112
Nissan	Armada	2005	7100	7109
Nissan	Sentra	2007	7092	7112
Nissan	X-Trail - Canada	1992 - 1999	7092	7112
Nissan	Titan	2004	7100	7109
Oldsmobile	Achieva	1992 - 1998	7090	7110
Oldsmobile	Alero	1999	7090	7110
Oldsmobile	Aurora	1995 - 1999	7090	7110
Oldsmobile	Cutlass	1997 - 1998	7090	7110
Oldsmobile	Intrigue	1999 - 2000	7090	7110
Pontiac	Firebird	1999 - 2002	7090	7110
Pontiac	G6	2005	7090	7110
Pontiac	Grand Am	1992 - 1999	7090	7110
Pontiac	Le Mans	1988 - 1993	7096	7104
Pontiac	Sunfire	1995 - 1999	7090	7110
Porsche	911	1999 -	7096	7104
Porsche	All others	All	7098	7111
Porsche	Boxter	1997 -	7096	7104
Renault	All	1985 - 1987	7094	7107
Saab	900	1978 - 1993	7094	7107
Saab	900	1994 - 1998	7096	7104
Saab	9000	1986 - 1998	7094	7107
Saab	9,3	2003 - 2004	7090	7110
Saab	900 Convertible	1994	7094	7107

Saturn	All (except L Series)	1990 - 1998	7100	7109
Saturn	All (except L Series)	1999	7090	7110
Saturn	Ion	2005	7090	7110
Saturn	Ion	2005	7100	7109
Saturn	L Series	1990 - 1999	7090	7110
Saturn	L Series	2000	7096	7104
Saturn	LS	1996	7100	7109
Saturn	LS	2000 - 2002	7096	7104
Saturn	Vue	2003	7090	7110
Saturn	Vue	2003	7100	7109
Scion	tC	All	7091	7113
Sterling	All	1987 - 1991	7094	7107
Subaru	All (w/small filler neck)	1994 -	7092	7112
Subaru	4 Cylinder	1984 - 2005	7092	7112
Subaru	Impreza	2006	7091	7113
Subaru	Legacy 4 Cylinder	1999 - 2005	7092	7112
Subaru	Outback 4 Cylinder	1999 - 2006	7092	7112
Subaru	Outback 6 Cylinder	2005	7091	7113
Subaru	Tribeca B9	2006	7091	7113
Suzuki	w/16mm deep filler neck	1983 - 1995	7092	7112
Suzuki	w/9.5MM deep filler neck	1989 - 1999	7091	7113
Toyota	4 Runner	1986 - 1995	7092	7112
Toyota	4 Runner	1996 - 2005	7091	7113
Toyota	Avalon	1995 - 2003	7092	7112
Toyota	Avalon	2011	7091	7113
Toyota	Camry	1983 - 1989	7092	7112
Toyota	Camry	1992 - 1993	7091	7113
Toyota	Camry (4-cylinder)	1994 - 2002	7091	7113
Toyota	Camry (V6, A/T)	1990 - 1991	7091	7113
Toyota	Camry (except V6 & A/T)	1990 - 1991	7092	7112
Toyota	Camry V6	1994 - 2005	7092	7112
Toyota	Celica	1983 - 1989	7092	7112
Toyota	Celica	1990 - 1998	7091	7113
Toyota	Celica (GTS-S)	2000	7103	7116
Toyota	Corolla	1983 - 1992	7092	7112
Toyota	Corolla	1993 - 2003	7091	7113
Toyota	Corolla S	2007	7091	7113
Toyota	Cressida	1985 - 1992	7092	7112
Toyota	Echo	2000 - 2003	7091	7113
Toyota	FJ	2007	7091	7113
Toyota	Highlander	2001 - 2003	7091	7113
Toyota	Highlander Hybrid	All	7103	7116
Toyota	Land Cruiser	1987 - 2002	7092	7112
Toyota	Matrix	2003	7091	7113
Toyota	MR2 Spyder	1985 - 1995	7092	7112
Toyota	MR2 Spyder	2000	7103	7116
Toyota	Paseo	1992 - 1999	7091	7113
Toyota	Pick-up	1983 - 1999	7092	7112
Toyota	Previa	1989 - 1997	7092	7112
Toyota	Prius	2001 - 2005	7103	7116
Toyota	RAV 4 (4-Cylinder)	2006	7103	7116
Toyota	RAV4	1996 - 2003	7091	7113
Toyota	Sequoia	2001 - 2003	7091	7113
Toyota	Sienna	1998 - 2003	7092	7112
Toyota	Sienna	2010	7091	7113
Toyota	Solara	1999 - 2002	7092	7112
Toyota	Starlet	1983 - 1984	7092	7112
Toyota	Supra	1994 - 1997	7091	7113

Toyota	Supra - non turbo	1986 - 1992	7092	7112
Toyota	Supra (turbo)	1990 - 1992	7091	7113
Toyota	T100	1995 - 1998	7092	7112
Toyota	Tacoma	2000 - 2002	7092	7112
Toyota	Tacoma	2006 - 2011	7091	7113
Toyota	Tercel	1983 - 1990	7092	7112
Toyota	Tercel	1991 - 1999	7091	7113
Toyota	Tundra	2000 - 2002	7091	7113
Toyota	Venza	2011	7091	7113
Toyota	Yaris	2011	7091	7113
Volvo	Passenger vehicles w/ threaded neck	1978 - 2007	7094	7107
Volvo	S40	2004 - 2010	7118	
Volvo	Trucks (w/ 47mm x 3mm threads on 2nd neck)	1978 - 2007	7094	7107
Volvo	V50	2005 - 2010	7118	
Volvo	All, except XC90	2008 - 2012	7118	
VW	Golf	1999 - 2004	7098	7111
VW	Jetta	1999 - 2004	7098	7111
VW	Jetta (new body 2005.5)	2005	7098	7111
VW	New Beetle	1998 - 2004	7098	7111
VW	Passat	1998 - 2004	7098	7111
VW	Touareg	2004	7098	7111
VW	with female threads on expansion tank	1990 - 1998	7095	7108
VW	with male threads on filler neck	1975 - 1993	7093	7106