Ready - to Run Installation

RED	TO COIL POSTIVE ⊕ 12 VOLTS
BLACK	TO COIL NEGATIVE ⊖

IGNITION KEY

TO 12V

BLACK

RED

COIL

⊖

⊕

Wiring the Ready-to-Run Distributor.